


NW-1000 USER'S GUIDE



Printed in China
LD7119001



Introduction

Thank you for purchasing the Brother NW-1000 High-Definition VideoCam. This web camera enables you to hold high-quality web conferences with your co-workers wherever they are located and whenever required. This guide contains basic procedures for setting up and using the NW-1000 web camera. We recommend reading this guide carefully before using the web camera and suggest keeping the guide handy for future reference. For updated product support information, visit the Brother Solutions Center at <http://solutions.brother.com/>.

Safety Precautions

WARNING	Tells you what to do to avoid accidents and the risk of injury.
CAUTION	Tells you about procedures you must follow to avoid minor personal injury or damage to the web camera.

WARNING

If you use the web camera and/or its accessories without following these warnings, you may create a risk of fire, electric shock, injury to yourself or others, or damage to the product.

- Do not allow the web camera to get wet in any way. For example, do not place the web camera near objects such as refrigerators or air conditioners, which may create condensation.
- Do not attempt to disassemble the web camera.
- Do not drop or hit the web camera.
- Do not use the web camera if you observe smoke, odor, heat, or noise coming from the device.
- Do not use the web camera if a foreign object, including but not limited to a paperclip, wire, etc., is in it.
- Do not damage or modify the USB cable that is connected to the web camera. Do not place heavy objects such as furniture on the cable, bend or pull the cable, or otherwise allow the cable to be pinched or constricted. Do not use any USB cable that has been damaged or modified.

If the web camera gets wet or has a foreign object in it, immediately disconnect the USB cable and contact the retail outlet where the web camera was purchased or your local authorized service center. To have the product inspected, adjusted, or maintained, contact the retail outlet where the web camera was purchased or your local authorized service center. If the web camera is damaged due to customer disassembling or attempting remodel, or repair, a service fee may be charged even during the warranty period.

CAUTION

- Do not place the web camera on any unstable surface or high shelf.
- Do not place heavy objects on top of the web camera. Doing so may cause injury if the web camera falls.
- Do not use or store the web camera in dusty places or any place where extremely high or low temperatures may occur, such as next to a heater.
- Keep the web camera out of both direct sunlight and rain.
- Do not leave the web camera within the reach of children, especially infants.

General Precautions

- Keep the product away from any sources of magnetic energy, such as magnetic cards, key fobs, or cathode-ray tubes.
- Do not clean the web camera with cleaning thinner, benzene, or other organic solvents.
- Wipe any dirt or dust off the web camera using a soft cloth. If necessary, use watered-down detergent to remove dirt.
- Do not touch the camera lens. Remove any dirt or dust on the lens using a lens blower.

Important Information

Troubleshooting and FAQs

For help with your device during setup or use, visit the Brother Solutions Center at <http://solutions.brother.com>.

Please record your model and serial number and the date and location of purchase below for your records. Keep this information with your proof of purchase (bill of sale) in case your product requires service.

Model # _____
Serial # _____
Date of purchase: _____
Name of reseller: _____
Reseller address: _____

Should you have further questions or need information about your Brother Product, contact our customer service center at: 1-855-809-5646

Important: We recommend that you keep all original packing materials, in the event you need to ship this product.

Save time – Register online!
Don't stand in line at the post office or worry about lost mail.
Visit us online to register and view our privacy policy: www.registermybrother.com

World Wide Web: www.brother-usa.com
Supplies/ Accessories: www.brothermall.com or 877-552-6255

Warranty

Brother™ Two -Year Limited Warranty and Replacement Service Web Conference Hardware (USA Only)

Who is covered:

- This limited warranty ("warranty") is given only to the original end-use/retail purchaser (referred to in this warranty as "Original Purchaser") of the accompanying product and accessories (collectively referred to in this warranty as "this Product").
- If you purchased a product from someone other than an authorized Brother reseller in the United States or if the product was used (including but not limited to floor models or refurbished product by someone other than Brother), prior to your purchase you are not the Original Purchaser and the product that you purchased is not covered by this warranty.

What is covered:

- This Product includes a Unit and Accessory Items. Accessory Items may include but are not limited to cable(s), adaptor, or carrying cases. Except as otherwise provided herein, Brother warrants that the Unit and the accompanying Accessory Items will be free from defects in materials and workmanship, when used under normal conditions.
- This warranty applies only to products purchased and used in the United States. For products purchased in, but used outside, the United States, this warranty covers only warranty service within the United States (and does not include shipping outside the United States).

What is the length of the Warranty Periods:

- Machine: two years from the original purchase date.
- Accompanying Accessory Items: 90 days from the original purchase date.

What is NOT covered:

This warranty does not cover:

- Physical damage to this Product;
- Damage caused by improper installation, improper or abnormal use, misuse, neglect or accident (including but not limited to transporting this Product without the proper preparation and/or packaging);
- Damage caused by another device or software used with this Product (including but not limited to damage resulting from use of non Brother™-brand parts and Accessory Items);
- Problems arising from other than defects in materials or workmanship.

This limited warranty is VOID if this Product has been altered or modified in any way (including but not limited to attempted warranty repair without authorization from Brother and/or alteration/removal of the serial number).

What to do if you think your Product is eligible for warranty service:

Report your issue to our Customer Service Hotline at 1-855-809-5646 within the applicable warranty period. Supply Brother with a copy of your dated bill of sale showing that this Product was purchased within the U.S.

What Brother will ask you to do:

After contacting Brother you will be required to send the product properly packaged, freight prepaid, to Brother together with a photocopy of your bill of sale. Brother will provide a **Return Authorization Number (i.e. RA#) that must be written on the outside of the carton that contains your product and instruction to where you should return your product. You are responsible for the cost of shipping, packing the product and insurance (if you desire). You are also responsible for loss or damage to this product in shipping.**

What Brother will do:

If the problem reported concerning your Unit and/or accompanying Accessory Items is covered by this warranty and if you first reported the problem to Brother within the applicable warranty period, Brother will repair or replace the Unit and/or accompanying Accessory Items at no charge to you for parts or labor. The decision as to whether to repair or replace the Unit and/or accompanying Accessory Items is made by Brother in its sole discretion. Brother reserves the right to supply a refurbished or remanufactured replacement Unit and/or accompanying Accessory Items and use refurbished parts, provided such replacement products conform to the manufacturer's specifications for new product/parts. The repaired or replacement Unit and/or accompanying Accessory Items will be returned to you freight prepaid.

If the Unit and/or accompanying Accessory Items are not covered by this warranty (either stage), you will be charged for shipping the Unit and/or accompanying Accessory Items back to you and charged for any service and/or replacement parts/products at Brother's then current published rates.

The foregoing are your sole (i.e., only) and exclusive remedies under this warranty.

What happens when Brother elects to replace your Unit:

Brother will send to you a replacement Unit with the understanding that you will, after receipt of the replacement Unit, supply the required proof of purchase information, together with the Unit that Brother agreed to replace. You are then expected to pack the Unit that Brother agreed to replace in the package from the replacement Unit and return it to Brother using the pre-paid freight bill supplied by Brother in accordance with the instructions provided by Brother. Since you will be in possession of two Units, Brother will require that you provide a valid major credit card number. Brother will issue a hold against the credit card account number that you provide until Brother receives your original Product and determines that your original Product is entitled to warranty coverage. Your credit card will be charged up to the cost of a new Product only if: (i) you do not return your original Product to Brother within five (5) business days; (ii) the problems with your original Product are not covered by the limited warranty; (iii) the proper packaging instructions are not followed and has caused damage to the product; or (iv) the warranty period on your original Product has expired or has not been sufficiently validated with a copy of the proof of purchase (bill of sale). The replacement Unit you receive (even if refurbished or remanufactured) will be covered by the balance of the limited warranty period remaining on the original Product, plus an additional thirty (30) days. You will keep the replacement Unit that is sent to you and your original Unit shall become the property of Brother. **Retain your original Accessory Items and a copy of the return freight bill, signed by the courier.**

Limitations:

Brother is not responsible for damage to or loss of any equipment, media, programs or data related to the use of this Product. Except for that repair or replacement as described above, Brother shall not be liable for any direct, indirect, incidental or consequential damages or specific relief. Because some states do not allow the exclusion or limitation of consequential or incidental damages, the above limitation may not apply to you.

THIS WARRANTY IS GIVEN IN LIEU OF ALL OTHER WARRANTIES, WRITTEN OR ORAL, WHETHER EXPRESSED BY AFFIRMATION, PROMISE, DESCRIPTION, DRAWING, MODEL OR SAMPLE. ANY AND ALL WARRANTIES OTHER THAN THIS ONE, WHETHER EXPRESS OR IMPLIED, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY DISCLAIMED.

- This Limited Warranty is the only warranty that Brother is giving for this Product. It is the *final expression and the exclusive and only statement of Brother's obligations* to you. It replaces all other agreements and understandings that you may have with Brother or its representatives.
- This warranty gives you certain rights and you may also have other rights that may vary from state to state.
- This Limited Warranty (and Brother's obligation to you) may not be changed in any way unless you and Brother sign the same piece of paper in which we (1) refer to this Product and your bill of sale date, (2) describe the change to this warranty and (3) agree to make that change.

Important: We recommend that you keep all original packing materials, in the event that you ship this Product.

© 2012 Brother International Corporation

Federal Communications Commission (FCC) Declaration of Conformity

Responsible Party:

Brother International Corporation
100 Somerset Corporate Boulevard
Bridgewater, NJ 08807-0911, U.S.A.
TEL : (908) 704-1700

declares that the product
Product Name: Brother Web Camera, NW-1000
Model Number: NW-1000

complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important

Changes or modifications not expressly approved by Brother Industries, Ltd. could void the user's authority to operate the equipment.


A specific shielded interface cable should be used in order to ensure compliance with the limits for a Class B digital device.

Industry Canada Compliance Statement

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

For detailed product specifications and the Declaration of Conformity, visit <http://solutions.brother.com>


Overview



- 1 Dual microphone
- 2 Auto focus lens
- 3 LED indicator*
- 4 USB jack
- 5 USB cable
- 6 User's Guide


* The indicator is lit when the camera is ready to use.

Setup




Placement

Laptop



Desktop



Large display



For detailed product specifications and the Declaration of Conformity, visit <http://solutions.brother.com>